

## 2015 and up TAHOE INSTALLATION FOR POLY VAULTS

Tools required: 7/16", 1/2", 18mm sockets -- 3/16", 5/32" Allen wrench, Phillips screwdriver



- 1) Remove drawers from unit. Tilt drawer up to get past stop block.  
**Make note of drawer locations as each drawer is fine tuned for its specific location.**
- 2) Remove fuse panel cover and tire changing equipment, on driver side (you will NOT reinstall this piece).
- 3) Slide Poly Vault into vehicle and line up with the vehicles threshold plate.
- 4) Install and tighten washer, lock washer, and bolt, into holes in floor. These should line up with threaded inserts.  
\*If your floor covers these threaded inserts, mark the hole locations, remove vault, and carefully cut a small section out of the carpet/vinyl to expose the threaded inserts.
- 5) Tilt both rear seats forward
- 6) Remove outer 18mm nuts on seat frame.
- 7) Install "Z" brackets to box and seat bolt studs and loosely place nut over stud. Reach inside box with 5/32" allen wrench to hold while tightening bracket hardware with 7/16" socket.
- 8) Retighten 18mm seat bolts to secure z-brackets
- 9) Re-insert drawers and install drawer stop hardware

STEP 1



STEP 2



STEP 3



STEP 4



STEP 5



STEP 6



STEP 7



STEP 8



STEP 9



If you need any assistance, don't hesitate to call us.

(281) 469-3451 or email [mike@pptexas.com](mailto:mike@pptexas.com)